

mafi natural wood floors in bathrooms

 3-layer floor

when installing mafi natural wood floors in a bathroom the following facts must be taken into consideration:

The planks must be full trowel glued to the Waterproofed sub floor firmly using an elastic timber flooring adhesive (we recommend SikaBond T55 or Sikabond T58).

Impregnate the cut edges (end sections that are glued with 5 mm distance to the wall) with mafi Wood Floor Oil so that the wood does not swell.

An expansion gap of min. 5 mm must be left at the edge – also when the join is with sanitary ware (baths, toilets, showers etc)

After installation the expansion gaps should be well sealed with parquet joint sealing compound/ silicon to act as a protection against "damp infiltration".

Subsequent treatment with the appropriate mafi Wood Floor Oil is absolutely necessary after installation. Massage the oil into the wood using a polishing cloth, at the same time absorbing any surplus with the cloth.

It takes about 10 days for the oil to dry completely. During this time the floor should only be walked on carefully and must not get wet or be wiped with a wet cloth.

After final hardening we recommend mopping the floor once or twice a week during the first month with Soap solution (see label on container). The protective oils contained in the soap make the floor more robust. Subsequent care is carried out as required using mafi Wood Floor Soap.

Please avoid pools of water on the wood's surface. Soak up water puddles immediately!

Please also note that with underfloor heating the surface temperature should not exceed 29°C.

